





# INSTRUCTIONS FOR: LOW NOISE BELT DRIVE COMPRESSOR MODEL No: SAC2203BLN.V2

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



**IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.**



## 1. SAFETY INSTRUCTIONS

### 1.1 ELECTRICAL SAFETY

**WARNING!** It is the responsibility of the owner and the operator to read, understand and comply with the following: You must check all electrical products, before use, to ensure that they are safe. You must inspect power cables, plugs, sockets and any other connectors for wear or damage. You must ensure that the risk of electric shock is minimised by the installation of appropriate safety devices. A Residual Current Circuit Breaker (RCCB) should be incorporated in the main distribution board. We also recommend that a Residual Current Device (RCD) is used. It is particularly important to use an RCD with portable products that are plugged into a supply which is not protected by an RCCB. If in any doubt consult a qualified electrician. You may obtain a Residual Current Device by contacting your Sealey dealer. You must also read and understand the following instructions concerning electrical safety.

- 1.1.1 The **Electricity at Work Act 1989** requires that all portable electrical appliances, if used on business premises, are tested by a qualified electrician, using a Portable Appliance Tester (PAT), at least once a year.
- 1.1.2 The **Health & Safety at Work Act 1974** makes owners of electrical appliances responsible for the safe condition of those appliances and the safety of the appliance operators. **If in any doubt about electrical safety, contact a qualified electrician.**
- 1.1.3 Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply. See 1.1.1. and 1.1.2. and use a Portable Appliance Tester.
- 1.1.4 Ensure that cables are always protected against short circuit and overload.
- 1.1.5 Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that none are loose.
- 1.1.6 **Important:** Ensure that the voltage marked on the appliance matches the power supply to be used and that the plug is fitted with the correct fuse.
- 1.1.7 **DO NOT** pull or carry the appliance by the power cable.
- 1.1.8 **DO NOT** pull the plug from the socket by the cable.
- 1.1.9 **DO NOT** use worn or damaged cables, plugs or connectors. Immediately have any faulty item repaired or replaced by a qualified electrician.
- 1.1.10 Twin capacitors and a centrifugal switch aid trouble free starting on a good 13Amp supply. In some cases a 16Amp supply may be required and **we recommend that a 16Amp industrial round pin plug should be fitted and connected to a 20Amp supply having a Type C breaker. If in doubt you must contact a qualified electrician to ensure that a suitably rated supply is available.**

- IMPORTANT!** The use of extension leads to connect these compressors to the mains is not recommended as the resulting voltage drop reduces motor, and therefore pump performance.
- 1.2 **GENERAL SAFETY INSTRUCTIONS**
  - Familiarise yourself with the application and limitations of the compressor.
  - Ensure the compressor is in good order and condition before use. If in any doubt **DO NOT** use the unit and contact an electrician/service agent.
  - WARNING! Compressor must only be serviced by an authorised agent. DO NOT tamper with, or attempt to adjust, pressure switch or safety valve.**
  - Before moving, or maintaining the compressor ensure it is unplugged from the mains supply and that the air tank pressure has been vented.
  - Maintain the compressor in good condition and replace any damaged or worn parts. Use genuine parts only. *Unauthorised parts may be dangerous and will invalidate your warranty.*
  - Read the instructions relating to any accessory to be used with this compressor. Ensure the safe working pressure of any air appliance used exceeds compressors output pressure. If using a spray gun, check that the area selected for spraying is provided with an air change system/ventilation.
  - Ensure the air supply valve is turned off before disconnecting the air supply hose.
  - Use the compressor in a well ventilated area and ensure it is placed on a firm surface.
  - Keep tools and other items away from the compressor when it is in use, and keep area clean and clear of unnecessary items.
  - Ensure the air hose is not tangled, twisted or pinched.
  - Keep children and unauthorised persons away from the working area.
  - DO NOT** dis-assemble compressor for any reason. The unit must be checked by qualified personnel only.
  - DO NOT** use the compressor outdoors, or in damp, or wet, locations.
  - DO NOT** operate within the vicinity of flammable liquids, gases or solids.
  - DO NOT** touch compressor cylinder, cylinder head or pipe from head to tank as these may be hot.
  - DO NOT** use this product to perform a task for which it has not been designed.

- X **DO NOT** deface the certification plate attached to the compressor tank.
- X **DO NOT** cover the compressor or restrict air flow around the unit whilst operating.
- **DANGER! DO NOT** direct the output jet of air towards people or animals.
- X **DO NOT** operate the compressor without an air filter.
- X **DO NOT** allow anyone to operate the compressor unless they have received full instructions.
- **WARNING!** The air tank is a pressure vessel and the following safety measures apply:
  - X **DO NOT** tamper with the safety valve, **DO NOT** modify or alter the tank in any way and **DO NOT** strap anything to the tank.
  - X **DO NOT** subject the tank to impact, vibration or to heat and **DO NOT** allow contact with abrasives or corrosives.
  - ✓ Drain condensation from tank and inspect the inside walls for corrosion according to the maintenance schedule, have a detailed tank inspection carried out annually. The tank shell must not fall below the certified thickness at any point.
  - **WARNING!** If an electrical fuse blows, ensure it is replaced with an identical fuse type and rating.
  - ✓ When not in use, store the compressor carefully in a safe, dry, childproof location.
  - ✓ When the compressor is not in use, it should be switched off, disconnected from the mains supply and the air drained from the tank.

## 2. INTRODUCTION & SPECIFICATIONS

### 2.1 INTRODUCTION

Heavy-duty low noise compressor suitable for garage, bodyshop and industrial applications. Fully enclosed, insulated design gives silent running and protects vital components from damage.


Heavy-duty single phase electric motor with soft start feature. Control box features tachometer for monitoring use and optimising service times.

### 2.2 SPECIFICATIONS

Model:.....	SAC2203BLN.V2
Motor Output (HP):.....	3
Voltage/Phase(V/1ph):.....	230/1
Input current(A):.....	16
Speed (rpm):.....	1075
Air Displacement (cfm/Lm):.....	15/425
Max Free Air Delivery (cfm/Lm):.....	10.9/309
Max Pressure (psi/bar):.....	145/10
Tank Capacity (Ltr):.....	200
Dimensions (WxDxHmm):.....	1440x440x900
Weight (kgs):.....	175
Sound Pressure db(A):.....	68
Sound Power LwA:.....	95




## 3. PREPARATION

- 3.1 Remove compressor from packaging and inspect for any shortages or damage. If anything is found to be missing or damaged contact your supplier.
- 3.2 Save the packing material for future transportation of the compressor. We recommend that you store the packing in a safe location, at least for the period of the guarantee. Then, if necessary, it will be easier to send the compressor to the service centre.
- 3.3 Confirm that the mains voltage corresponds with the voltage shown on the compressor data plate.
- 3.4 Position the compressor on a flat surface or with a maximum permissible inclination of 10°. Site in a well ventilated place, protected against atmospheric pollution and not in a place subject to explosion hazard. If the surface is in a raised position, make sure it cannot fall, securing it in a suitable way.



- 3.5 To ensure good ventilation and efficient cooling, the compressor must be at least 100cm from any wall. Compressors fitted on the tank, with fixed feet, should not be rigidly secured to the ground. Fit the 4 anti-vibration supports, raise the compressor using a suitable pallet truck or fork lift and push the supports onto the base of each foot (fig.3).
- 3.6 Take care to transport the compressor correctly, **DO NOT** overturn it or lift it with hooks or ropes.
- 3.7 Before using the compressor, check the oil level by observing the sight glass as shown in fig.5. If the oil is not up to the max mark it should be topped up with synthetic oil suitable for temperatures ranging from -5°C to 45°C (viscosity 5W50). We do not recommend using mineral oil in these compressors. **DO NOT** overfill.

**NOTE:** To gain access to the pump and motor you must remove the 4 bolts from the top lid of the sound proof casing. For some servicing such as draining oil, you must also remove the rear panel by removing the 4 bolts.



## 4. OPERATION

- ❑ **WARNING!** Ensure that you have read, understood and apply Section 1 safety instructions.
- ❑ **IMPORTANT!** The use of extension leads to connect this compressors to the mains is not recommended as the resulting voltage drop reduces motor, and therefore pump performance and could cause damage to your compressor.

*NOTE:* Take care when selecting tools for use with the compressor. Air tool manufacturers normally express the volume of air required to operate a tool in cubic feet per minute (cfm). This refers to free air delivered by the compressor ('air out') which varies according to the pressure setting. Do not confuse this with the compressor displacement which is the air taken in by the compressor ('air in'). 'Air out' is always less than 'air in' due to losses within the compressor.

### 4.1 STARTING THE COMPRESSOR

To turn the compressor on, plug mains lead into mains supply, press the "ON" button on the front panel See fig.6.

- 4.1.1 When starting the compressor for the first time, leave it running with no air tools connected to the air outlet. Make sure that pressure in the tank rises and that the compressor stops automatically when the maximum pressure value allowed (written on the plate and shown on the gauge in fig.6) is achieved. The compressor will now operate automatically. The pressure switch stops the motor when the maximum tank pressure is reached and restarts it when the pressure falls below the minimum threshold - approx. 2bar (29psi) less than the maximum pressure.
- 4.1.2 Stop the compressor by pressing the "OFF/RESET" button in fig.6. The compressed air inside the compressor head will flow out, making the restart easier and preventing the motor from being damaged. **DO NOT**, other than in an emergency, stop the compressor by switching off the mains power, or by pulling the plug out, as the pressure relief will not then operate and motor damage may result upon restart.
- 4.1.3 The motor of the compressor is fitted with a thermal breaker. The manual resetting button is doubled up with the "OFF" button (fig.6). When the breaker is tripped, wait for a few minutes and then press the reset button. If the unit keeps tripping investigate and rectify the cause.  
**NOTE:** If the motor does not cut in and out, but runs continuously when using an air appliance, the capacity of the compressor may be too small for the equipment or tool.  
**WARNING! DO NOT tamper with, or adjust, the switch or safety valve.**

## 5. MAINTENANCE


In order to keep the compressor in good working condition, periodic maintenance is essential.

**IMPORTANT!** Failure to carry out maintenance tasks may invalidate the warranty on your compressor.

**Inspection of pressure tank both inside and out.** Under the PRESSURE SYSTEMS SAFETY REGULATIONS 2000 it is the responsibility of the owner of the compressor to initiate a system of inspection that both defines the frequency of the inspection and appoints a person who has specific responsibility for carrying out the inspection.

- ❑ **WARNING!** Before performing any maintenance operation, switch off the compressor, disconnect from electricity supply and release all air from the tank (except for 5.3.a)  
**Note!** To gain access to the pump and motor you must remove the 4 bolts from the top lid of the sound proof casing. For some servicing such as draining oil, you must also remove the rear panel by removing the 4 bolts.
- 5.1 **OPERATIONS TO BE CARRIED OUT AFTER THE FIRST 50 WORKING HOURS:**
  - a) Check that all bolts/nuts are tight, particularly those retaining the crankcase and cylinder head.
  - b) Replace the lubricating oil - see para 5.4.
- 5.2 **OPERATIONS TO BE CARRIED OUT WEEKLY:**
  - a) Drain condensation by opening the valve located under the tank (fig.8). Place a container under the valve and open the valve by turning anti-clockwise.

- ❑ **WARNING!** Take care if there is still pressure inside the cylinder as water could flow out with considerable force. Recommended pressure 1 - 2bar max.
- b) Check oil level and, if necessary, top up.
- 5.3 **OPERATIONS TO BE CARRIED OUT EVERY 50 - 100 HOURS:** (or more frequently, if the compressor operates in a very dusty atmosphere):
  - a) Remove the air filter element (fig.7). Using stored air from the compressor's tank, clean the filter with compressed air. (Wear eye protection and **DO NOT** direct air towards the body or hands). **DO NOT** operate the compressor without the filter as foreign bodies or dust could seriously damage the pump. Replace the filter element and air filter housing.
  - b) Check for oil leaks.
  - c) Check the automatic cut-out at max. pressure and the automatic cut-in at 2bar below.
- 5.4 **OPERATIONS TO BE CARRIED OUT EVERY 400 - 500 HOURS DEPENDING ON CONDITIONS (IF THE COMPRESSOR OPERATES IN A DUSTY OR HARSH ATMOSPHERE USE 400 HOURS)**
  - a) Replace the lubricating oil. For oil specifications see 5.6. Remove the filler/breather plug (see fig.4-B) then open oil drain tap, draining the oil into a container. Drain when the compressor is hot so that the oil drains rapidly and completely. Replace oil drain plug and refill through the filler/breather aperture. **DO NOT** overfill. Check sight glass for correct level. Replace plug.
- ❑ **WARNING!** Never mix different oils and do not use non-detergent/low quality oils as the compressor may be damaged.
- ❑ **WARNING!** Dispose of waste oil only in accordance with local authority requirements.
  - b) Replace air filter. (See fig.7)
  - c) Check all tube fittings and electrical connections.
  - d) Inspect pressure tank inside and out for damage or corrosion.



### 5.5 MAINTENANCE SCHEDULE

Maintenance Operations	Weekly	50-100hrs	4-500hrs
Drain condensation	●		
Check oil level	●	●	
Clean intake filter		●	
Check for oil leaks		●	
Replace oil			●
Check cut-out		●	
General cleaning of compressor		●	
Replace air filter			●
Check tube fittings and electrical connections			●

**5.6 RECOMMENDED OILS**

Synthetic oil suitable for temperatures ranging from -5°C to 45°C: viscosity 5W50. We do not recommend using mineral oil in this compressors.

Part No.	Qty	Description
FSO1	1ltr x 12	Compressor oil fully synthetic
FSO1S	1ltr x 1	Compressor oil fully synthetic
FSO5	5ltr x 1	Compressor oil fully synthetic

**5.7 IMPORTANT WARNING**

**WARNING** - Air contaminants taken into the compressor will affect optimum performance. Example: Body filler dust or paint over-spray will clog the pump intake filter and may cause internal damage to pump/motor components. Please note that any parts damaged by any type of contamination will not be covered by warranty.




fig.7




fig.9

**6. TROUBLE SHOOTING**

Fault	Cause	Remedy
Pressure drop in the tank.	Air leaks at connections.	Run compressor to max. pressure, switch off. Brush soap solution over connections and look for bubbles. Tighten connections showing leaks. If problem persists contact Authorised Service Agent.
Pressure switch valve leaks when compressor is idle.	Non-return valve seal defective.	Discharge all tank pressure. Referring to fig.9, unscrew valve cap 'A'. Clean rubber disc 'B' and its seat. Refit all parts accurately.
Compressor stops and does not restart.	Power failure. Motor failure.	Check electricity supply and fuse. Contact Authorised Service Agent.
Compressor does not stop at max pressure.	Pressure switch fault.	Contact Authorised Service Agent.
Compressor does not reach max pressure.	Filter clogged. Head gasket or valve fault.	Replace filter element. Contact Authorised Service Agent.
Compressor noisy with metallic knock.	Low oil level. Bearing or piston damage.	Turn off and top up oil immediately. Contact Authorised Service Agent.




fig.8



**Environmental Protection.**

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycle centre and disposed of in a manner which is compatible with the environment.



**WEEE Regulations.**

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment. When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

Parts support is available for this product. To obtain a parts listing and/or diagram, please log on to [www.sealey.co.uk](http://www.sealey.co.uk), email [sales@sealey.co.uk](mailto:sales@sealey.co.uk) or phone 01284 757500.

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**IMPORTANT:** No liability is accepted for incorrect use of this product.

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.

**INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



**Sole UK Distributor, Sealey Group,**  
Kempson Way, Suffolk Business Park,  
Bury St. Edmunds, Suffolk,  
IP32 7AR



01284 757500



[www.sealey.co.uk](http://www.sealey.co.uk)



01284 703534



[sales@sealey.co.uk](mailto:sales@sealey.co.uk)

