



INSTRUCTIONS FOR MOTORCYCLE & BICYCLE WHEEL BALANCER & TRUING STAND

MODEL No: **WTS01**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY



Refer to
instruction
manual

GENERAL SAFETY

- ❑ **WARNING!** *Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this tool.*
- ❑ **WARNING!** Familiarise yourself with the specific applications and limitations of the tool as well as any potential hazards.
- ✓ This tool should be used in conjunction with inspection maintenance procedures recommended in the vehicle manufacturer's manual.
- ✓ Ensure that the tool is correct for the task.
- ✓ Wear the appropriate personal protective equipment for the task. A full range is available from your Sealey dealer.
- ✗ **DO NOT** use the tool for any purpose other than that for which it is designed.
- ✓ Ensure there is adequate lighting prior to using the tool.
- ✓ Keep children and unauthorised persons away from the working area.
- ✗ **DO NOT** use the tool if any parts are damaged or missing, as this may cause failure and/or personal injury.
- ✗ **DO NOT** use the tool when you are tired, or under the influence of alcohol, drugs or intoxicating medication.
- ✓ After use, store in a safe, dry childproof area.

2. INTRODUCTION


Professional design ideal for the workshop technician or competent DIY enthusiast. Enables the accurate balancing after tyre fitting and truing of warped or buckled spoke wheels. Includes two cones and spindle for precise, easy alignment and balancing. Uses gravity to find the heavy point of a wheel and tyre. Also has threaded centring stabilizer bolts to securely hold the wheel whilst truing the rim. Truing is done by adjusting the tension of the spokes.

3. SPECIFICATION

Model No: **WTS01**
Maximum Cone Size Balancer: $\text{Ø}37.5\text{mm}$
Centre Balancer Spindle to Base: 585mm
Maximum Cone Size Truing Axle: $\text{Ø}37\text{mm}$
Centre Truing Axle to Base: 445mm

4.1. Assembling the Stand. See fig.1.




- 4.1.1. Screw the two uprights to the base, with the bearings facing inwards, using 8 x hex headed screws and nuts.
- 4.1.2. Screw the threaded bolts through the uprights and screw a cone onto each one.
- 4.1.3. Screw the four feet into the base and use a spirit level to ensure the stand is level.
- 4.1.4. Place the cones on to the spindle and place the spindle onto the bearings.
- 4.1.5. Slide the truing pointer into its holder and tighten the holding screw. The pointer can be adjusted up and down by undoing the nut on the back.



3.2. Wheel Balancing See figs. 2, 3, 4 & 5

3.2.1. Use the stand on a stable, level surface. If necessary adjust the feet until frame is level.

- 3.2.2. Slide the spindle through the motorcycle wheel hollow axle and slide a cone onto either end of the spindle so that the tapered ends enter the wheel bearings. When the wheel is central on the spindle, secure the cones by tightening the grub screw in each using a 3mm hex key. Check that the wheel is central on the spindle and firmly secured by the cones for best results, see fig.4.
- 3.2.3. With the wheel securely on the stand, gently rotate the wheel. When the wheel settles, the spot at the bottom of the wheel is the heavy spot.
- 3.2.4. Now with the heavy spot at the bottom mark the top of the wheel directly opposite the heavy spot using chalk or adhesive tape. This is the light spot, see fig.5A.
- 3.2.5. Gently spin the wheel again to ensure that the heavy spot will again settle at the bottom, see fig.5.
- 3.2.6. Attach some wheel weights to the rim of the wheel at the light spot (fig.5A) and spin the wheel gently.
- 3.2.7. If the light spot falls to the bottom, too much weight has been added to the wheel. If the heavy spot falls to the bottom, not enough weight has been added to the wheel. Add / Remove weight as required, see fig.6.
- 3.2.8. Turn the light spot 90 degrees so it sits horizontally with the heavy spot and observe its movements, if again it falls to the bottom, too much weight has been added, if the heavy spot falls, too little weight has been added, see fig.6.
- 3.2.9. Repeat until the light spot and heavy spot are on a horizontal line through the centre of the wheel. Once this has been achieved the wheel should rest still at any position through the wheels circumference.



WARNING! Sealey can not accept responsibility for incorrect use of this product. The end user should seek appropriate advice before use.

3.3. Wheel Truing See fig.3

- 3.3.1 Use the threaded centring bolts to securely hold the wheel whilst truing the rim.
- 3.3.2. Tools Required:
 - Spoke wrench (Sealey MS037)
 - Spoke torque wrench
 - Dial gauge (optional)

3.4. Lateral Run Out

- 3.4.1. Spin the wheel to see if there is Lateral Run Out.
- 3.4.2. Loosen the nut on the pointer and set it as close to the wheel as possible.
Note: Only tighten spokes in quarter turn increments.
- 3.4.3. If the spinning wheel moves close to the pointer at some point, tighten the spokes on the opposite side to move the wheel rim away from the pointer.
- 3.4.4. If the wheel moves away from the pointer, tighten the spokes on the side nearest the pointer.
Note: the severity of the run out determines how many spokes (usually) three and how many turns are made.
- 3.4.5. Continue adjusting until the run out has gone from the wheel. **Check manufacturer's data for run out tolerances.**

- 3.4.6. Use the torque wrench to tighten the spokes from this point on.
- 3.4.7. Start at the valve hole, tighten the first spoke, skip two spokes and tighten every fourth spoke a quarter turn. (This keeps equal tension on the rim.)
- 3.4.8. When you get back to the beginning (the valve hole), move from the first spoke to the second spoke, tighten every fourth spoke a quarter turn.
- 3.4.9. When you get back to the beginning, move to the third spoke, tighten every fourth spoke a quarter turn.
- 3.4.10. When you get back to the beginning, every spoke should have been tightened.
- 3.4.11. Spin the wheel to check for trueness.

3.5. Radial Run Out

- 3.5.1. Spin the wheel to check for low and high points.
- 3.5.2. If the pointer denotes a low spot, tighten every spoke near it to raise the wheel towards the hub.
- 3.5.3. If the pointer denotes a high spot, loosen the spokes, to bring the rim away from the hub.
- 3.5.4. Retorque the spokes as above refer to 3.4.6. to 3.4.11. It may take two rounds of torquing to achieve good results.
- 3.5.5. Check the run out again and adjust,
- 3.5.6. It is at this point that a dial gauge could be used to achieve more accurate result.



Environmental Protection.

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycle centre and disposed of in a manner which is compatible with the environment.

Parts support is available for this product. To obtain a parts listing and/or diagram, please log on to www.sealey.co.uk, email sales@sealey.co.uk or telephone 01284 757500.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.



Sole UK Distributor, Sealey Group,
Kempson Way, Suffolk Business Park,
Bury St. Edmunds, Suffolk,
IP32 7AR



01284 757500

01284 703534



www.sealey.co.uk

sales@sealey.co.uk