


# 4 TONNE BODY REPAIR KIT

■ STOCK No.37874. ■ PART No.BR4/KIT.


## PARTS LISTING AND DRAWING

05/2000

### HYDRAULIC SPREADER ASSEMBLY



### HYDRAULIC RAM ASSEMBLY



KEY No.	PART No.	STOCK No.	DESCRIPTION
S1	YBR4 - S01	38432	Lower duck bill
S2	YBR4 - S02	38433	Spring
S3	YBR4 - S03	38434	Upper duck bill
S4	YBR4 - S04	38435	Pivot pin
S5	YBR4 - S05	38436	Circlip
S6	YBR4 - S06	38437	Piston
S7	YBR4 - S07	38438	Cup seal
S8	YBR4 - S08	38439	O-ring
S9	YBR4 - S09	38440	End cap
S10	YBR4 - S10	38441	Coupling ring
S11	YBR4 - S11	38442	Coupling bolt
S12	YBR4 - S12	38443	O-ring
S13	YBR4 - S13	38444	Dust cap

KEY No.	PART No.	STOCK No.	DESCRIPTION
R01	YBR4 - R01A "SS"	38445	Cylinder
R04	YBR4 - R04 "SS"	38446	Ram
R05	YBR4 - R05	38447	O-ring
R06	YBR4 - R06	38448	Piston Ring
R07	YBR4 - R07	38449	O-ring
R08	YBR4 - R08	38450	Cup
R09	YBR4 - R09	38455	O-ring
R10	YBR4 - R10	38460	Washer
R11	YBR4 - R11	38461	Circlip
S11	YBR4 - S11	38442	Coupling bolt
R12	YBR4 - R12	38462	Spring
S12	YBR4 - S12	38443	O-ring
R13	YBR4 - R13	38463	Screw
S13	YBR4 - S13	38444	Dust cap
R14	YBR4 - R14	38464	Ring

**Helpline: (023) 8049 4344. Sales Desk: (023) 8049 4333. General Enquiries: (023) 8026 6355.**


# 4 TONNE BODY REPAIR KIT

■ STOCK No.37874. ■ PART No.BR4/KIT.

## SPARE PARTS LISTING

05/2000


HYDRAULIC BODY AND  
FRAME PUMP.



KEY No.	PART No.	STOCK No.	DESCRIPTION
P01	YBR4 - P01	38465	Pump housing
P02	YBR4 - P02	38466	Filter
P03	YBR4 - P03	38467	Seal
P04	YBR4 - P04	38468	Pump reservoir
P05	YBR4 - P05	38469	Reservoir end cap
P06	YBR4 - P06	38470	Pump foot
P07	YBR4 - P07	38471	Hex nut
P08	YBR4 - P08	38472	O-ring
P09	YBR4 - P09	38473	Dip stick
P10	YBR4 - P10	38474	Ball valve
P11	YBR4 - P11	38475	Ball valve
P12	YBR4 - P12	38476	Spring
P13	YBR4 - P13	38477	Overload screw
P14	YBR4 - P14	38478	O-ring
P15	YBR4 - P15	38479	Release valve stem
P16	YBR4 - P16	38480	Seal
P17	YBR4 - P17	38481	O-ring
P18	YBR4 - P18	38482	Clamping nut

KEY No.	PART No.	STOCK No.	DESCRIPTION
P19	YBR4 - P19	38483	O-ring
P20	YBR4 - P20	38484	Piston
P21	YBR4 - P21	38485	Handle bracket
P22	YBR4 - P22	38486	Piston pin
P23	YBR4 - P23	38487	Bracket pin
P24	YBR4 - P24	38488	Circlip
P25	YBR4 - P25	38489	Pump handle
P26	YBR4 - P26	38490	Handle grip
P27	YBR4 - P27	38491	Hose
P28	YBR4 - P28	38492	Coupling
P29	YBR4 - P29	38493	Dust cap
P30	YBR4 - P30	38494	Steel ball
P31	YBR4 - P31	38495	Spring plunger
P32	YBR4 - P32	38496	Spring
P33	YBR4 - P33	38497	O-ring
P34	YBR4 - P34	38498	Screw (safety valve)
P35	YBR4 - P35	38499	Plastic cap

## 4 TON BODY REPAIR KIT



KEY No.	PART No.	STOCK No.	DESCRIPTION
1	YBR4 - A1	38719	Metal storage case
2	YBR4 - A2	38720	495mm Extension bar
3	YBR4 - A3	38721	420mm Extension bar
4	YBR4 - A4	38722	215mm Extension bar
5	YBR4 - A5	38723	100mm Extension bar
6	YBR4 - A6	38724	85mm Extension bar
7	YBR4 - A7	38725	Serrated cap
8	YBR4 - A8	38726	Hydraulic spreading wedge
9	YBR4 - A9	38727	Rubber head 60mm diameter

KEY No.	PART No.	STOCK No.	DESCRIPTION
10	YBR4 - A10	38728	Flat serrated base
11	YBR4 - A11	38729	Ram toe
12	YBR4 - A12	38730	Plunger toe
13	YBR4 - A13	38731	Cleft head
14	YBR4 - A14	38732	'V' base
15	YBR4 - A15	38733	Double end male connector
16	YBR4 - A16	38734	4 Tonne pump unit
17	YBR4 - A17	38735	Hydraulic push ram unit
18	YBR4 - A18	38736	Hydraulic hose

**Helpline: (023) 8049 4344. Sales Desk: (023) 8049 4333. General Enquiries: (023) 8026 6355.**