


10 TONNE BODY REPAIR KIT

■ STOCK No.37875. ■ PART No.BR10/KIT.


PARTS LISTING AND DRAWING

05/2000

HYDRAULIC SPREADER ASSEMBLY



HYDRAULIC RAM ASSEMBLY



KEY No.	PART No.	STOCK No.	DESCRIPTION
S1	YBR10 - S01	38500	Lower duck bill
S2	YBR10 - S02	38501	Spring
S3	YBR10 - S03	38502	Upper duck bill
S4	YBR10 - S04	38503	Pivot pin
S5	YBR10 - S05	38504	Circlip
S6	YBR10 - S06	38505	Piston
S7	YBR10 - S07	38506	Cup seal
S8	YBR10 - S08	38507	O-ring
S9	YBR10 - S09	38508	End cap
S10	YBR10 - S10	38510	Coupling ring
S11	YBR10 - S11	38511	Coupling bolt
S12	YBR10 - S12	38512	O-ring
S13	YBR10 - S13	38513	Dust cap

KEY No.	PART No.	STOCK No.	DESCRIPTION
R01	YBR10 - R01A "SS"	38514	Cylinder
R04	YBR10 - R04 "SS"	38515	Ram
R05	YBR10 - R05	38516	O-ring
R06	YBR10 - R06	38517	Piston Ring
R07	YBR10 - R07	38518	O-ring
R08	YBR10 - R08	38519	Cup
R09	YBR10 - R09	38520	O-ring
R10	YBR10 - R10	38521	Washer
S10	YBR10 - S10	38510	Coupling ring
R11	YBR10 - R11	38522	Circlip
S11	YBR10 - S11	38511	Coupling bolt
R12	YBR10 - R12	38523	Spring
S12	YBR10 - S12	38512	O-ring
R13	YBR10 - R13	38524	Screw
S13	YBR10 - S13	38513	Dust cap
R14	YBR10 - R14	38525	Ring
R15	YBR10 - R15	38526	Protection cap
R16	YBR10 - R16	38527	Nut

Helpline: (023) 8049 4344. Sales Desk: (023) 8049 4333. General Enquiries: (023) 8026 6355.


10 TONNE BODY REPAIR KIT

■ STOCK No.37875. ■ PART No.BR10/KIT.

SPARE PARTS LISTING

05/2000


HYDRAULIC BODY AND
FRAME PUMP.



KEY No.	PART No.	STOCK No.	DESCRIPTION
P01	YBR10 - P01	38531	Pump housing
P02	YBR10 - P02	38532	Filter
P03	YBR10 - P03	38533	Seal
P04	YBR10 - P04	38534	Pump reservoir
P05	YBR10 - P05	38535	Reservoir end cap
P06	YBR10 - P06	38536	Pump foot
P07	YBR10 - P07	38537	Hex nut
P08	YBR10 - P08	38538	O-ring
P09	YBR10 - P09	38539	Dip stick
P10	YBR10 - P10	38540	Ball valve
P11	YBR10 - P11	38541	Ball valve
P12	YBR10 - P12	38542	Spring
P13	YBR10 - P13	38543	Overload screw
P14	YBR10 - P14	38544	O-ring
P15	YBR10 - P15	38545	Release valve stem
P16	YBR10 - P16	38546	Seal
P17	YBR10 - P17	38547	O-ring
P18	YBR10 - P18	38548	Clamping nut

KEY No.	PART No.	STOCK No.	DESCRIPTION
P19	YBR10 - P19	38549	O-ring
P20	YBR10 - P20	38550	Piston
P21	YBR10 - P21	38551	Handle bracket
P22	YBR10 - P22	38552	Piston pin
P23	YBR10 - P23	38553	Bracket pin
P24	YBR10 - P24	38554	Circlip
P25	YBR10 - P25	38555	Pump handle
P26	YBR10 - P26	38556	Handle grip
P27	YBR10 - P27	38557	Hose
P28	YBR10 - P28	38558	Coupling
P29	YBR10 - P29	38559	Dust cap
P30	YBR10 - P30	38560	Steel ball
P31	YBR10 - P31	38561	Spring plunger
P32	YBR10 - P32	38562	Spring
P33	YBR10 - P33	38563	O-ring
P34	YBR10 - P34	38564	Screw (safety valve)
P35	YBR10 - P35	38565	Plastic cap

10 TON BODY REPAIR KIT



KEY No.	PART No.	STOCK No.	DESCRIPTION
1	YBR10 - A1	38737	Metal storage case
2	YBR10 - A2	38738	685mm Extension bar
3	YBR10 - A3	38739	455mm Extension bar
4	YBR10 - A4	38740	250mm Extension bar
5	YBR10 - A5	38741	100mm Extension bar
6	YBR10 - A6	38742	Serrated cap
7	YBR10 - A7	38743	Hydraulic spreading wedge
8	YBR10 - A8	38744	Rubber head 80mm diameter
9	YBR10 - A9	38745	Flat serrated base

KEY No.	PART No.	STOCK No.	DESCRIPTION
10	YBR10 - A10	38746	Ram toe
11	YBR10 - A11	38747	Plunger toe
12	YBR10 - A12	38748	Cleft head
13	YBR10 - A13	38749	'V' base
14	YBR10 - A14	38750	Double end male connector
15	YBR10 - A15	38751	10 Ton pump unit
16	YBR10 - A16	38752	Hydraulic push ram
17	YBR10 - A17	38753	Hydraulic hose

Helpline: (023) 8049 4344. Sales Desk: (023) 8049 4333. General Enquiries: (023) 8026 6355.