

DRAPER®

®

INSTRUCTIONS FOR Rechargeable Battery Packs

Stock Nos.41898 & 41900 Part No.CB143 & CB183

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY TO ENSURE THE SAFE AND EFFECTIVE USE OF THIS PRODUCT.



CE

DRAPER®

GENERAL INFORMATION

Read all these instructions before operating this product and save these instructions.

This manual has been compiled by Draper Tools and is an integrated part of the product with which it is enclosed and should be kept with it for future references.

This manual describes the purpose for which the product has been designed and contains all the necessary information to ensure its correct and safe use. We recommend that this manual is read before any operation or, before performing any kind of adjustment to the product and prior to any maintenance tasks. By following all the general safety instructions contained in this manual, it will ensure both product and operator safety, together with longer life of the product itself.

All photographs and drawings in this manual are supplied by Draper Tools to help illustrate the operation of the product.

Whilst every effort has been made to ensure accuracy of information contained in this manual, the Draper Tools policy of continuous improvement determines the right to make modifications without prior warning.



SPECIFICATION

STOCK No.:	PART No.:	VOLTAGE:
41898	CB143	14.4V (1.2Ah)
41900	CB183	18V (1.2Ah)

CHARGING:

This battery was discharged after manufacturing and will therefore require five to ten charges/discharges before it reaches its full capacity.

SAFETY INSTRUCTIONS FOR RECHARGEABLE BATTERIES:

Do not expose to rain or water.

Do not overcharge the battery as this may damage the battery cells.

Ensure that the battery pack is not exposed to direct sunlight, domestic heaters or other sources of heat.

Temperatures of more than 50°C and high moisture levels will damage the battery pack.

HEALTH AND SAFETY FOR BATTERY PACKS:

General

Do not put in a fire or mutilate - the cells may burst or release toxic materials.

Do not short circuit the cells as they may cause burns.

Disposal

Do not mutilate the batteries as corrosive electrolyte will be released.

Do not incinerate - danger of explosion and toxic fumes will be released.

Do not dispose of batteries or cells when they are in a charged condition.

Expired nickel-cadmium batteries must be recycled/disposed of in accordance with the appropriate regulations legislation. They should be returned to your local stockist.

- **DRAPER TOOLS LIMITED,**
Hursley Road,
Chandler's Ford,
Eastleigh,
Hampshire.
SO53 1YF. U.K.
- **Helpline:** (023) 8049 4344.
- **Sales Desk:** (023) 8049 4333.
- **General Enquiries:** (023) 8026 6355.
- **Fax:** (023) 8026 0784
- **Internet:** www.drapertools.co.uk
- **E-mail:** sales@drapertools.com

YOUR DRAPER STOCKIST

RDJH 181006

©Published by Draper Tools Limited.

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical photocopying, recording or otherwise without prior permission in writing from Draper Tools Ltd.