


HVLP SPRAY GUN

■ PART No.HVLP2 (SECTION FEED)
■ PART No.HVLP3 (GRAVITY FEED)

■ STOCK No.54436
■ STOCK No.54437

SPARE PARTS LISTING

10/97



KEY No.	PART No.	STOCK No.	DESCRIPTION
1a	BH088821	54588	Nozzle assembly 1.3
1b	BH088822	54589	Nozzle assembly 1.5
1c	BH088823	54590	Nozzle assembly 1.7
1d	BH088824	54591	Nozzle assembly 1.9
2	BS088536	54592	Plug
3	BH088546	54593	Trigger pin
4	BL088498	54594	Trigger
5	BS088450	54595	Piston cover
6	BU088846	54596	Body
7	BH088548	54597	Regulator assembly
8	BH088165	54598	Air control piston

KEY No.	PART No.	STOCK No.	DESCRIPTION
9	BA108014	54599	Needle spring
10	BS088085	54601	Guide washer
11	BD088086	54602	Piston seal
12	BS088118	54603	Bush
13	BI088114	54604	Needle nut
14	BH088547	54605	Air regulator
15	BH088606	54606	Suction feed cup (HVLP 2)
16	AH088511	54607	Filter (HVLP 2)
17	BH088697	54608	Gravity feed cup (HVLP 3)
18	AH088521	54609	Filter (HVLP 3)