

RECHARGEABLE BATTERY PACKS

STOCK Nos.: 54451. **PART Nos.:** CB96.

54452. CB12.

54453. CB14.

57808. CB14A.

57809. CB18.

INSTRUCTIONS •

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY TO ENSURE THE SAFE AND EFFECTIVE USE OF THIS TOOL.





SPECIFICATION

STOCK Nos.	PART Nos.	VOLTAGES:
54451.	CB96.	9.6V.
54452.	CB12.	12 V .
54453.	CB14.	14.4V.
57808.	CB14A.	14.4V (2.0AH.).
57809.	CB18.	18V (2.0AH.).

CHARGING:

This battery was discharged after manufacturing and will therefore require five to ten charges/discharges before it reaches its full capacity.

SAFETY INSTRUCTIONS FOR RECHARGEABLE BATTERIES:

Do not expose to rain or water.

Do not overcharge the battery as this may damage the battery cells.

Ensure that the battery pack is not exposed to direct sunlight, domestic heaters or other sources of heat.

Temperatures of more than 50°C and high moisture levels will damage the battery pack.

HEALTH AND SAFETY FOR BATTERY PACKS:

General

Do not put in a fire or mutilate - the cells may burst or release toxic materials.

Do not short circuit the cells as they may cause burns.

Disposal

Do not mutilate the batteries as corrosive electrolyte will be released.

Do not incinerate - danger of explosion and toxic fumes will be released.

Do not dispose of batteries or cells when they are in a charged condition.

Expired nickel-cadmium batteries must be recycled/disposed of in accordance with the appropriate regulations legislation. They should be returned to your local stockist.





DRAPER TOOLS LIMITED,

Hursley Road, Chandler's Ford, Eastleigh, Hants. SO53 1YF. England.

Tel: (023) 8026 6355. Fax: (023) 8026 0784.

©Published by Draper Tools Ltd.

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical photocopying, recording or otherwise without prior permission in writing from Draper Tools Ltd.