


# PARTS LISTING

MACHINE: 1/2" SQ. DRIVE HEAVY DUTY  
AIR IMPACT WRENCH.

MACHINE STOCK No.55111 and 55360.

MACHINE PART No.4201HDA and 4201HDKA.

06/98



KEY No.	PART No.	STOCK No.	DESCRIPTION
1	Y4201HDA-1	55207	Protecting rubber
2	Y4201HDA-2	55208	Oil seal
3	Y4201HDA-3	55209	Housing
4	Y4201HDA-4	55210	Anvil bushing
5	Y4201HDA-5	55211	Spacer
6	Y4201HDA-6	55212	O-ring
7	Y4201HDA-7	55213	Anvil collar
8	Y4201HDA-8	55214	Anvil
9	Y4201HDA-9	55215	Spring
10	Y4201HDA-10	55216	Hammer pin
11	Y4201HDA-11	55217	Cam
12	Y4201HDA-12	55218	Steel ball
13	Y4201HDA-13	55219	Drive cam foundation
14	Y4201HDA-14	55220	Hammer cage
15	Y4201HDA-15	55221	Ball bearing
16	Y4201HDA-16	55222	O-ring
17	Y4201HDA-17	55223	Oil seal
18	Y4201HDA-18	55224	Front end plate
19	Y4201HDA-19	55225	Cylinder
20	Y4201HDA-20	55226	Rotor
21	Y4201HDA-21	55227	Rotor blade
22	Y4201HDA-22	55228	Rear end plate
23	Y4201HDA-23	55229	Ball bearing
24	Y4201HDA-24	55230	Rear gasket
25	Y4201HDA-25	55231	Rear cover
26	Y4201HDA-26	55232	Spring washer
27	Y4201HDA-27	55233	Cap screw

KEY No.	PART No.	STOCK No.	DESCRIPTION
28	Y4201HDA-28	55234	Spring washer
29	Y4201HDA-29	55235	Cap screw
30	Y4201HDA-30	55236	Oil screw
31	Y4201HDA-31	55237	Exhaust deflector
32	Y4201HDA-32	55238	Pin
33	Y4201HDA-33	55239	Spring
34	Y4201HDA-34	55240	Set screw
35	Y4201HDA-35	55241	Valve sleeve
36	Y4201HDA-36	55242	Reverse valve
37	Y4201HDA-37	55243	Trigger
38	Y4201HDA-38	55244	Pin
39	Y4201HDA-39	55245	Pin
40	Y4201HDA-40	55246	Valve block gasket
41	Y4201HDA-41	55247	Valve block
42	Y4201HDA-42	55248	Cap screw
43	Y4201HDA-43	55249	Hose adaptor
44	Y4201HDA-44	55250	O-ring
45	Y4201HDA-45	55251	Air regulator
46	Y4201HDA-46	55252	Screw
47	Y4201HDA-47	55253	O-ring
48	Y4201HDA-48	55254	Valve stem
49	Y4201HDA-49	55255	O-ring
50	Y4201HDA-50	55256	Throttle valve
51	Y4201HDA-51	55257	O-ring
52	Y4201HDA-52	55258	Spring
54	Y4201HDA-54	55259	Protecting rubber

**POWER DIVISION HELP LINE: 01703 494344**