

14.4V (1.7Ah) RECHARGEABLE BATTERY PACK

STOCK No.56727

■ PART No.APG6

• INSTRUCTIONS •

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY TO ENSURE THE SAFE AND EFFECTIVE USE OF THIS TOOL.

CHARGING:

This battery was discharged after manufacturing for testing and will therefore require five to ten charges/discharges before it reaches its full capacity.

SAFETY INSTRUCTIONS FOR RECHARGEABLE BATTERIES:

Do not expose to rain or water.

Do not overcharge the battery (more than 24 hours) as this may damage the battery cells.

Ensure that the battery pack is not exposed to direct sunlight, domestic heaters or other sauces of heat.

Temperatures of more than 40° C and high moisture levels will damage the battery pack.

HEALTH AND SAFETY FOR BATTERY PACKS:

General

Do not put in a fire or mutilate - the cells may burst or release toxic materials.

Do not short circuit the cells as they may cause burns.

Disposal

Do not mutilate the batteries as corrosive electrolyte will be released.

Do not incinerate - danger of explosion and toxic fumes will be released.

Do not dispose of batteries or cell when they are in a charged condition.

Expired nickel-cadmium batteries must be recycled/disposed of in accordance with the appropriate regulations legislation. They should be returned to your local warranty agent/stockist.

