



INSTRUCTIONS FOR:

ROLLCAB 5 DRAWER with BALL BEARING RUNNERS

MODEL No: **AP22505BB**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY

1.1 GENERAL SAFETY

- WARNING!** Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this product.
- WARNING!** Use caution when handling and assembling the metal components. The metal may have sharp edges or corners, the use of protective gloves is recommended.
- DO NOT open more than one drawer at a time.
- DO NOT step on the drawers.
- DO NOT let children near the rollcab.
- Ensure all drawers are fully closed and the self locking catch is activated, before moving the rollcab.
- Secure the brakes when rollcab is in the desired position
- Keep the work area clean, uncluttered and ensure there is adequate lighting.
- Keep the mounting frame clean and tidy in accordance with good workshop practice.
- DO NOT** use in damp work areas.
- WARNING!** The warnings, cautions and instructions referred to in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood that common sense and caution are factors which cannot be built into this product, but must be applied by the operator.





2. INTRODUCTION

Features smooth 25mm ball bearing drawer runners, side handle, cylinder lock and, for additional security, rear locking bars to secure drawers when not in use. Supplied with two keys.

3. ASSEMBLY

- 3.1. Attach the castors to the bottom of the trolley (fig.1) using 4 bolts and washers per castor.
- Note:** The swivel castors should be mounted on the same side as the side handle (left hand side).
- 3.2. Insert the side handle into the cabinet with four bolts and washers (fig.2).



4. MAINTENANCE

- 4.1. Lubricate the castors and check the castor fixings periodically.

Parts support is available for this product. To obtain a parts listing and/or diagram, please log on to www.sealey.co.uk, email sales@sealey.co.uk or telephone 01284 757500.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



Sole UK Distributor, Sealey Group,
Kempson Way, Suffolk Business Park,
Bury St. Edmunds, Suffolk,
IP32 7AR

01284 757500

01284 703534



www.sealey.co.uk



sales@sealey.co.uk