



INSTRUCTIONS FOR: SIDE CABINET FOR LONG HANDLE TOOLS - RED/BLACK

MODEL No's: **APLHT/APLHTB**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY

1.1. GENERAL SAFETY

- ❑ **WARNING!** Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this cabinet.
- ✓ Keep the work area clean, uncluttered and ensure there is adequate lighting.
- ✓ Keep the cabinet clean and tidy in accordance with good workshop practice.
- ✓ Keep children and unauthorised persons away from the work area.
- x **DO NOT** use this cabinet for any purpose other than that for which it is designed.
- x **DO NOT** place the cabinet in a damp or wet location or an area where there is condensation.
- x **DO NOT** clean the cabinet with any solvents which may damage the surfaces or the protective coating.

2. INTRODUCTION

Lockable storage unit for long tools, such as prybars, long reach screwdrivers and breaker bars. Hangs on side of rollcab and can be fastened securely to side for added security. A range of different diameter support holes provide great versatility of storage options. Supplied with lock and two keys.

3. SPECIFICATION

Model No:	APLHT/APLHTB
Overall Size W x D x H:	410 x 90 x 272mm
Support Hole Ø x Quantity:	25mm x 6, 17mm x 4, 15mm x 16

4. ASSEMBLY

- 4.1. Fit foam pads to back of the side cabinet to prevent damage to the rollcab.
- 4.2. The side cabinet can be hung from the rollcab, but it is recommended that the side cabinet is secured to the rollcab, using the two self tapping screws and two flat washers provided.
- 4.3. Hang the side cabinet on the rollcab and open it up. Ensure it is centrally positioned and mark the intended position of the holes to be drilled. Refer to fig.2.
- 4.4. Remove the side cabinet and drill the two holes in to the roll cab using a 4.8mm (3/16") drill bit.
- 4.5. Re-hang the side cabinet and secure to the rollcab using the two self tapping screws and two flat washers provided.



Fig.1




Fig.2



Fig.3

Parts support is available for this product. To obtain a listing and/or diagram, please log on to: www.sealey.co.uk,
email: sales@sealey.co.uk or phone: 01284 757500



Environmental Protection.

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycle centre and disposed of in a manner which is compatible with the environment.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



Sole UK Distributor, Sealey Group,
Kempson Way, Suffolk Business Park,
Bury St. Edmunds, Suffolk,
IP32 7AR



01284 757500

01284 703534



www.sealey.co.uk



sales@sealey.co.uk