


Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.




IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE OR PERSONAL INJURY, AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

1.1. ELECTRICAL SAFETY

- WARNING!** It is the responsibility of the owner and the operator to read, understand and comply with the following:
- You must check all electrical products, before use, to ensure that they are safe. You must inspect power cables, plugs, sockets and any other connectors for wear or damage. You must ensure that the risk of electric shock is minimised by the installation of appropriate safety devices. A Residual Current Circuit Breaker (RCCB) should be incorporated in the main distribution board. We also recommend that a Residual Current Device (RCD) is used. It is particularly important to use an RCD with portable products that are plugged into a supply which is not protected by an RCCB. If in any doubt consult a qualified electrician. You may obtain a Residual Current Device by contacting your Sealey dealer.
- You must also read and understand the following instructions concerning electrical safety.
- 1.1.1. The Electricity at Work Act 1989 requires that all portable electrical appliances, if used on business premises, are tested by a qualified electrician, using a Portable Appliance Tester (PAT), at least once a year.
- 1.1.2. The Health & Safety at Work Act 1974 makes owners of electrical appliances responsible for the safe condition of those appliances and the safety of the appliance operators. If in any doubt about electrical safety, contact a qualified electrician.
- 1.1.3. Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply. See 1.1.1 and 1.1.2 and use a Portable Appliance Tester.
- 1.1.4. Ensure that cables are always protected against short circuit and overload.
- 1.1.5. Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that none is loose.
- 1.1.6. Important: Ensure that the voltage marked on the appliance matches the power supply to be used and that the plug is fitted with the correct fuse - see fuse rating at right.
- 1.1.7. **DO NOT** pull or carry the appliance by the power cable.
- 1.1.8. **DO NOT** pull the plug from the socket by the cable.
- 1.1.9. **DO NOT** use worn or damaged cables, plugs or connectors. Immediately have any faulty item repaired or replaced by a qualified electrician. When a BS 1363/A UK 3 pin plug is damaged, cut the cable just above the plug and dispose of the plug safely. Fit a new plug according to the following instructions (UK only).
- Connect the **GREEN/YELLOW earth wire to the earth terminal 'E'**.
 - Connect the **BROWN live wire to the live terminal 'L'**.
 - Connect the **BLUE neutral wire to the neutral terminal 'N'**.
- d) After wiring, check that there are no bare wires, that all wires have been correctly connected, that the cable outer insulation extends beyond the cable restraint and that the restraint is tight. Double insulated products, which are always marked with this symbol , are fitted with live (brown) and neutral (blue) wires only. To rewire, connect the wires as indicated above - **DO NOT** connect either wire to the earth terminal.
- 1.1.10. Products which require more than 13 amps are supplied without a plug. In this case you must contact a qualified electrician to ensure that a suitably rated supply is available. We recommend that you discuss the installation of an industrial round pin plug and socket with your electrician.
- 1.1.11. If an extension reel is used it should be fully unwound before connection. A reel with an RCD fitted is preferred since any appliance plugged into it will be protected. The cable core section is important and should be at least 1.5mm², but to be absolutely sure that the capacity of the reel is suitable for this product and for others which may be used in the other output sockets, we recommend the use of 2.5mm² section cable.



1.2. GENERAL SAFETY

- ✓ Disconnect the fan from the mains power when not in use, and before servicing or performing any maintenance.
- ✓ Use the fan in dry areas only. Do not use in wet or high condensation locations such as bathrooms, showers, or pools.
- WARNING!** If fan falls into water, immediately disconnect from the mains power supply. **Do not touch the fan until the mains power supply has been disconnected.**
- ✓ Always disconnect the fan from the power supply when moving it from one location to another.
- ✓ Keep the fan clean and maintained in good condition (use an authorised service agent).
- ✓ Use recommended parts only (unauthorised parts may be dangerous, and will invalidate your warranty).
- x **DO NOT** insert any objects through the fan guard.
- x **DO NOT** cover the fan.
- x **DO NOT** immerse the fan in water or any other liquid.
- x **DO NOT** allow children to operate the fan.
- x **DO NOT** place the fan where it may be knocked over easily, or where the lead may cause a person to trip.
- x **DO NOT** use the fan outdoors.
- x **DO NOT** use an extension cord unless it has been approved by an electrical authority.
- ✓ When not in use store in a safe, dry, childproof location.

USE BY PERSONS WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAPABILITIES.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

2. INTRODUCTION & SPECIFICATION

Clip-on fan featuring tilt and swivel head for optimum air circulation. Switch control and fully guarded fan blades for ease of use and extra safety. Smooth running motor powers fan blades.

Fan Diameter: 203mm(8")
 Speeds: 2
 Maximum Air Flow: 15mtr³/min
 Power: 20W
 Input: 230V
 Height: 360mm

3. OPERATION

- ❑ **WARNING! Ensure you read, understand and apply the safety instructions in Section 1 before using the fan.**
 - ❑ **WARNING! Do not clamp the light to any electrical or sensitive electronic equipment or any surface or object that is too flimsy to resist the force of the spring loaded clamp and/or the weight of the fan.**
- 3.1. Mount the fan in a suitable location, using the spring loaded clamp to attach it to a suitable table, shelf or other stable solid surface up to 36mm thick as indicated in figs.1 & 2.
 - 3.2. Adjust the angle of the head as indicated in fig.2C. Loosen knob 'B' and set the fan to the required angle, re-tighten the knob.
 - 3.3. If necessary, the whole fan can be rotated on the clamp as indicated in fig.2A.
 - 3.4. The fan can also be wall mounted using the keyhole slots on the clamp as shown in fig.1A.
 - 3.5. Plug the fan into the mains power supply.
 - 3.6. Move slide switch on the rear of the fan head to position "1" for normal fan speed operation, and to position "2" for high fan speed. To stop the fan, move the slide switch to the central 'OFF' position. See fig.3.




fig.1

4. CARE OF FAN

IMPORTANT: Turn the fan **OFF** and disconnect from power supply before cleaning.

- 4.1. Use only a soft, damp cloth to clean the fan.
- 4.2. **DO NOT** submerge the fan in water and **NEVER** allow water to drip into the motor housing.
- 4.3. **DO NOT** use solvents or other chemicals to clean the fan.
- 4.4. Store the fan in its original box or otherwise cover the fan to protect it from dust.




fig.2




fig.3

Parts support is available for this product. To obtain a parts listing and/or diagram, please log on to www.sealey.co.uk, email sales@sealey.co.uk or phone 01284 757500.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



Sole UK Distributor, Sealey Group,
 Kempson Way, Suffolk Business Park,
 Bury St. Edmunds, Suffolk,
 IP32 7AR

☎ 01284 757500

🌐 www.sealey.co.uk

☎ 01284 703534

✉ sales@sealey.co.uk