

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY, AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

NOTE! This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. The Sealey Hand Pressure Sprayer Model No SS2 is safe and only becomes a safety issue when used with toxic fluids. The following safety instructions are bullet points and cannot cover every aspect of user safety.


- ✓ Be aware of the safety requirements (C.O.S.H.H.) for the fluids contained in the vessel.
- ✓ Wear safety equipment as advised in (C.O.S.H.H.) statements.
- ✓ Do read and follow all the fluid manufacturers instructions for application and safe use.
- ✓ Store the vessel inside an outbuilding away from foodstuffs and out of reach of children.
- ✓ Label vessel with chemical used, even if water. It is highly recommended that individual vessels should be used for individual chemicals. Cross contamination can give unexpected results. Also possible spillages are avoided in transferring liquids.
- x **DO NOT** spray at people, animals, protected insect species, in high winds, at naked flames or sources of heat.
- x **DO NOT** use the pressure sprayer for any purpose other than for which it is designed.
- x **DO NOT** use whilst eating, drinking, smoking; under the influence of drugs, alcohol, intoxicating medication, or if fatigued.
- x **DO NOT** use to spray flammable liquids, solvents etc..

2. INTRODUCTION

Ideal for spraying a wide variety of fluids including water, herbicides, insecticides, fungicides and solvent free preservative treatments. Features a handle with two functions, pressurisation and filler cap removal. A 350mm long metal lance fitted with an adjustable nozzle to switch between mist and jet settings, a plastic grip handle, operating lever and 1100mm of plastic hose. The pressure vessel incorporates a spring return pressure relief valve which can be operated manually and two lugs for a carrying strap. Capacity 5ltr (8.5 pints).

3. OPERATION

- 3.1 Grip the dual purpose handle (A) and engage with drive tangs on filler cap (B), holding the vessel rotate the filler cap to remove.
- 3.2 Avoiding spillages, fill to 5L maximum or required volume.
- 3.3 Re-attach filler cap, keeping vessel vertical. With the dual purpose handle, engage with tangs on filler cap, holding the vessel rotate until filler cap is hand tight against the neck seal.
- 3.4 Attach a label with contents indicated.
- 3.5 Pressurise (A) as shown in illustration. Pressure can be reduced manually via the spring return pressure release valve (C).
- 3.6 Operate the trigger (E) to spray and rotate the nozzle to obtain desired spray mode, rotate nozzle fully to close.
- 3.7 After use, operate pressure relief valve to depressurise the vessel.
- 3.8 Flush externally with water to clean off residuals and store safely after use.



Environmental Protection. Recycle unwanted packaging materials or dispose of in a manner which is compatible with the environment. When the product is no longer required, dispose of in an environmentally protective way.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.